

## Seat Lift Chair


Seat lift chairs are specifically designed to assist individuals in coming to a standing position, but there are many additional benefits to these power reclining/ standing assist products. A lift chair offers the comfort, convenience, and safety not afforded by a regular recliner. A lift chair places your body in a more therapeutically correct position where legs are elevated to a height that enhances circulation; the back reclines to a level that reduces stress on the heart, joints and back.

### Placement

Your lift chair should be placed near a standard electrical outlet on dry, levelground where there is ample room to allow for proper operation. Follow these steps to position the lift chair in a safe manner:

1. Place the back of the lift chair 30 inches from the nearest obstruction while the chair is in the seated position.
2. Position the low voltage connection cable where it will not be pinched between the frame and the lift mechanism.
3. Connect the low voltage connection cable to the external transformer if it is not already connected. Plug the power cord directly into the electrical outlet. Do not use an extension cord!

NOTE: If you discover a problem at any point during the setup and positioning of your lift chair, stop and contact us immediately. To avoid personal injury and/or product damage, do not plug the unit into the electrical outlet until the problem is corrected and do not attempt to fix electrical problems by yourself.



### Battery Installation

Your lift chair may be equipped with a battery backup system that will activate during a power failure. The backup system is powered by two 9V batteries that need to be installed into the external transformer. Follow these steps to install the batteries:

1. Unplug the external transformer power cord from the electrical outlet.
2. Open the marked battery door on the external transformer.
3. Install two 9V batteries into the external transformer
4. Replace the battery door.

NOTE: Always make sure the external transformer is equipped with two fresh 9V batteries, since the battery backup system does not recharge itself.

NOTE: If you unplug your lift chair for an extended period of time (more than one hour), remove the batteries from the external transformer. The lift chair will draw power from the batteries even when it is not in use.

## In Case of a Power Failure

The batteries will provide power for only a short period of time after power is removed from the system, so it is important to act quickly in the event of a power failure. Press and hold the UP button on the hand control as soon as possible. Maintain a steady pressure on the button to avoid excessive draw from the battery and achieve the most amount of lift. Keep in mind that the amount of lift the batteries will be able to provide is affected by user weight and battery condition.

## Warnings

Pinch/Crush Points: Hazard! Be aware that the lift mechanism and scissor mechanisms are a pinch point on the lift chair. Keep the following items and similar objects clear of these points when operating the lift chair:

- Appendages
- Small children
- Pets
- Wires
- Oxygen and/or nebulizer tubing
- Loose items, including but not limited to clothing and blankets
- Electrical power cords

## Operation Precautions

There are certain precautions that should be taken during the operation of your lift chair. Read and follow these precautions carefully in order to ensure safe lift chair operation and to prevent injury and/or product damage.

- Stay within the specified weight capacity of your lift chair (325 lbs).
- Plug the power cord directly into the electrical outlet. **Do not use an extension cord!**
- Do not place anything (for example, a drinking glass) on top of or near the external transformer.
- If the external transformer box or hand control requires cleaning, unplug the power cord from the electrical outlet and use a clean, dry cloth or lightly dampened cloth. Allow ample drying time before plugging the power cord back into the electrical outlet.
- Periodically check the hand control and all power cords for visible damage.
- Keep the hand control away from all heated surfaces.
- Ensure the hand control is out of the way before sitting in the chair.
- Keep children and pets away from all moving parts while operating the lift chair.
- Do not allow children to play on or operate the lift chair. Only the intended user should operate the lift chair.
- Keep the hand control locked or utilize the quick-disconnect feature on the standard hand control when the lift chair is not in use to prevent unintended operation of the chair.
- Avoid pinch points, such as the lift and scissor mechanisms. Keep hands and feet clear of these areas.
- Always leave the lift chair in an upright and closed position when not in use.
- Do not sit or stand on the footrest.
- Do not “drop” into the lift chair when sitting if it is in a partially raised position.